

iProMOH Quick Start

1 CONNECT TO INTERNET

- DHCP must be enabled on router.
- STATIC config upon request.
- Uses port 80.

2 CONNECT POWER




- Unit connects to server upon power-up.

3 CONNECT TO PHONE SYSTEM

- Channel 1 / 600-Ohms out.
- RCA connector.



STATUS INDICATOR LIGHT

FLASHING AMBER		ATTEMPTING CONNECTION
FLASHING GREEN		NORMAL
FLASHING GREEN/RED		CANNOT CONNECT TO SERVER

TROUBLESHOOTING TIPS

- Router must be able to assign I.P. from active DHCP pool.
- If using static settings, contact Easy On Hold support.
- Port 80 must be free of restrictions.
- Reboot unit to attempt connection.

Do not use the installer application or attempt to change settings. Call-home I.P. address and other requested settings were made prior to shipping the unit to you.

CONTACT EASY ON HOLD

1-888-798-4653 8:30am to 5pm Eastern Time

ONLINE RESOURCES

VIDEO: <http://easynhold.com/support/anytime-plan>

COMPLETE MANUAL: <http://easynhold.com/support>